

GV-QFER12700





© 2021 GeoVision, Inc. All rights reserved.

Under the copyright laws, this manual may not be copied, in whole or in part, without the written consent of GeoVision.

Every effort has been made to ensure that the information in this manual is accurate. GeoVision, Inc. makes no expressed or implied warranty of any kind and assumes no responsibility for errors or omissions. No liability is assumed for incidental or consequential damages arising from the use of the information or products contained herein. Features and specifications are subject to change without notice.

Note: No memory card slot or local storage function for Argentina.

GeoVision, Inc. 9F, No. 246, Sec. 1, Neihu Rd., Neihu District, Taipei, Taiwan Tel: +886-2-8797-8377 Fax: +886-2-8797-8335 http://www.geovision.com.tw

Trademarks used in this manual: *GeoVision*, the *GeoVision* logo and GV series products are trademarks of GeoVision, Inc. *Windows* is the registered trademark of Microsoft Corporation.

June 2021



Contents

No	te for	Connecting to GV-VMS / DVR / NVR	ii
No	te for	Recording	ii
1.	Intro	oduction	1
	1.1	Packing List	1
	1.2	Overview	1
	1.3	Wire Definitions	2
2.	Inst	allation	3
3.	Con	necting the Camera	5
	3.1	Power Connection	5
	3.2	Waterproofing the Cable	5
4.	Acc	essing the Camera	7
	4.1	System Requirements	7
	4.2	Looking Up the Dynamic IP Address	8
	4.3	Configuring the IP Address	9
5.	The	Web Interface1	0
	5.1	Viewing Live View Video	0
6.	Upg	rading System Firmware1	2
7.	Res	toring to Factory Default1	3

GeoVision:

Note for Connecting to GV-VMS / DVR / NVR

The GV-QFER12700 is designed to work with GV-VMS / DVR / NVR, a video management system. Note the following when the camera is connected to GV-VMS / DVR / NVR:

Once the camera is connected to the GV-VMS / DVR / NVR, the resolution set on the GV-VMS / DVR / NVR will override the resolution set on the camera's Web interface. You can only change the resolution settings through the Web interface when the connection to the GV-VMS / DVR / NVR is interrupted.

Note: Currently, only GV-VMS, applied with the patches, supports GV-QFER12700.

Note for Recording

Mind the following when using a memory card for recording:

- Recorded data on the memory card can be damaged or lost if the data are accessed while the camera is under physical shock, power interruption, memory card detachment or when the memory card reaches the end of its lifespan. No guarantee is provided for such causes.
- The stored data can be lost if the memory card is not accessed for a long period of time. Back up your data periodically if you seldom access the memory card.
- Memory cards are expendable and their durability varies according to the conditions of the installed site and how they are used. Back up your data regularly and replace the memory card annually.
- To avoid power outage, it is highly recommended to apply a battery backup (UPS).
- For better performance, it is highly recommended to use Micro SD card of MLC NAND flash, Class 10.
- Replace the memory card when its read/write speed is lower than 6 MB/s or when the memory card is frequently undetected by the camera.
- To ensure smooth network usage, do not access the live view from more than 20 connections.



1. Introduction

Welcome to the *GV-QFER12700 Quick Start Guide*. In the following sections, you will learn the basic installations and configurations. For a detailed user manual, see the <u>*GV-QFER12700</u>* <u>*User's Manual*</u>.</u>

1.1 Packing List

- GV-QFER12700
- Self-Tapping Screw x 3
- Plastic Anchor x 3
- Torx Wrench
- Waterproof Rubber Set
- 4-Pin Alarm I/O Terminal Block
- Download Guide
- Warranty Card

1.2 Overview



No.	Description			
1	IR LED x 4			
2	Default Button			
3	Micro SD card slot			

GeoUision

1.3 Wire Definitions



No.	Description			
1	Audio In (Pink)			
1	Audio Out (Green)			
2	4-Pin Alarm I/O Terminal Block			
3	3 Power (DC 12V)			
4 RJ-45 / PoE				



2. Installation

In this chapter, you will learn how to install GV-QFER12700 with standard package.

Required Items

- Tool for drilling a hole on the ceiling (user-prepared)
- M4 Crosshead Screw Driver (user-prepared)
- SD card (user-prepared)
- 1. Loosen the two screws on the dome cover with the supplied torx wrench, and remove the dome cover by pulling it apart from the camera.



2. Place the camera on the desired ceiling or wall and mark the two screw holes.



- 3. Drill the marked screw holes and insert the supplied plastic anchors.
- 4. Align the two screw holes on the camera with the inserted plastic anchors. Fasten the camera with the supplied self-tapping screws.
- 5. Close and secure the dome cover.



Note: GV-QFER12700 can be installed to the wall or ceiling with GV-Mount206-1 / 903-2 / 904-2 / 912-1 / 919. Refer to the following sections and documents.

- GV-Mount 206-1 (*5.4.2 GV-FER5701 / FER12203 / FER12700 / EFER3700 / EFER3700-W / QFER12700*, GV-Mount Accessories Installation Guide)
- GV-Mount903-2 (*5.1.2 GV-EFER3700 / GV-EFER3700-W / GV-QFER12700*, GV-Mount Accessories Installation Guide)
- GV-Mount904-2 (5.6.2 GV-Mount904-1, GV-Mount Accessories Installation Guide)
- GV-Mount912-1 (5.12 Power Box Mount, GV-Mount Accessories Installation Guide)
- GV-Mount919 (Appendix C: In-Ceiling Mount Installation, GV-QFER12700 User's Manual)

3. Connecting the Camera

3.1 **Power Connection**

To power up the camera, choose one of the following options below.

- Connect the DC 12V power adaptor (optional accessory) to the power connector of the camera and the power outlet.
- Connect an Ethernet cable to the RJ-45 connector of the camera and a GV-PA191 PoE Adapter (optional accessory).

3.2 Waterproofing the Cable

Audio / Alarm I/O Cable

Follow the steps below to waterproof the Audio / Alarm I/O cables.

 Connect the required devices to the camera and apply sealant such as silicone on holes, voids and gaps which have potential risk to water leakage. There should be no gap between the connectors and the cables.



2. Seal the end of the rubber coating of the cables as indicated in the figure below. Use enough silicone gel to fill in the hose and wrap around each wire; otherwise, waterproof function cannot be guaranteed.

RJ-45 Cable

Follow the steps below to waterproof the RJ-45 cable.

1. Insert the waterproof components through the Ethernet cable as shown below.



Insert in order



2. Insert the cable into the RJ-45 plug.



3. Assemble the waterproof rubber set.



4. If the DC cable is not in use, you can waterproof it by inserting the supplied plug into the DC interface.



4. Accessing the Camera

4.1 System Requirements

Once installed, your camera is accessible over the network. Make sure your PC has good network connection, and meet the following requirements:

Operating System	Windows 7 or later			
Memory	Minimum: 4 GB			
	Recommended: 8 GB			
CPU	Minimum: Intel Core i5-2430M, 2.4 GHz			
	Recommended: Intel Core i7-870, 2.93 GHz			
Web Browser	 Microsoft Internet Explorer 11.0 (recommended) 			
	Google Chrome			
	Mozilla Firefox			
	Microsoft Edge			
	Safari			

Note: The live view of the main stream is playable on non-IE browsers only in MJPEG format.

GeoVision:

4.2 Looking Up the Dynamic IP Address

By default, when the camera is connected to LAN with a DHCP server, it is automatically assigned with a dynamic IP address. Follow the steps below to look up its IP address and set up a login password.

Note: The PC installed with GV-IP Device Utility must be under the same LAN as your camera.

- 1. Download and install the GV-IP Device Utility program from the company website.
- 2. On the GV-IP Utility window, click the Q button to search for the IP devices connected in the same LAN. Click the **Name** or **Mac Address** column to sort.
- 3. Find the camera with its MAC Address, and click on its IP address.



4. The dialog box appears for you to create a new password.

			×
MacAddress	0013E2243345	IP Address 192.168.4.46	
User Login			
User Name	admin	VSS Port 80	
Password	*****		
Create User Accou	Int		
New Passw	ord		
Confirm Nev	v Password		
Password st	trength	Weak	
For safety	reasons please cha	inge vour new password must be at least 8 characters	
long. It mus	st contain three of the owercase letters (a-z)	following character categories: uppercase letters (A-Z),), digits (0-9), or special character (!^,+[]{=).	
, Dpgrade	e all devices		

Note: By default, the Administrator's username is admin and cannot be modified.



5. Type the desired password and click **Save**. The login page appears.

GeoUision			
A			
8 **	a a w a r d		
	Loge		

6. Type the username **admin** and your password. Click **Login**.

4.3 Configuring the IP Address

By default, the GV-QFER12700, connected to LAN without a DHCP server, is assigned with a static IP address of **192.168.0.10**. Follow the steps below to assign a new IP address to avoid IP conflict with other GeoVision devices.

- 1. Open your Web browser, and type the default IP address **192.168.0.10**.
- 2. For the first-time user, you will be asked to create a new password.
- 3. Type the username admin and your password. Click Login.
- 4. Click System, select Network in the left menu and select Basic.
- 5. Select Use fixed IP address.
- 6. Type the IP address, subnet mask, and default gateway address. Make sure that the IP address of the camera is unique in the network.

GeoVision	Home System	Streaming Image	Logout			
System	Network					
Security	General					
Network 🔺	O Get IP address auton	natically				
Basic	Use fixed IP address	Use fixed IP address				
QoS	IP address	192.168.4.13				
SNMP	Subnet mask	255.255.248.0				
UPnP	Default gateway	192.168.0.1				
DDNS	Primary DNS	168.95.1.1				
Mail	Secondary DNS	8.8.8.8				
FTP	O Use PPPoE					

7. Click Save.

Note: See details in 2.2.3 Network, GV-QFER12700 User's Manual.



5. The Web Interface

5.1 Viewing Live View Video

Once you log in the Web interface, you will see the live view as shown below.



No.	Name	Function				
1	Video Quality	Show or hide the bitrate and compression of each stream.				
2	Full Screen	Display in full screen mode.				
3	Talk	Turn on 📵 or off 重 outward audio transmission.				
4	Listen	Turn on 💿 or off 🕙 inward audio transmission.				
5	Snapshot	Click to save JPEG snapshots.				
6	Live View Pause	Pause or restart video streaming.				
7	Record	Turn on ● or off 💿 video recording.				
8	Manual Trigger	Turn on 🚳 or off 🅘 the manual trigger.				
9	Fisheye View	Turned on \bullet by default. Click to turn off \odot .				
		Turn on 🔎 or off 💭. Hold left-click and drag the pointer				
10	Single View	in any direction to pan and tilt, or scroll the mouse				
		wheel to zoom in and out.				



11	Dual 180 Degree	Ceiling Mount	Turn on 🔎 or off 🦳 Hold left-click to pan 180°.	
	180 Degree	Wall Mount	Turn on 回 or off . Hold left-click and drag the pointer +• to tilt 180°.	
12	Quad View	Ceiling Mount	Turn on or off . Hold left-click and drag the pointer in any direction to pan and tilt, or scroll the mouse wheel to zoom in and out.	
	360 Degree	Wall Mount	Turn on or off . For the top grid, hold left-click and drag the pointer to tilt 180°. For the bottom grids, hold left-click and drag the pointer in any direction to pan and tilt, or scroll the mouse wheel to zoom in and out.	
Note: No. 11 and 12 varies based on the type of Installation selected in Fisheye Setting. For				
details, see Step 3 in 2.4.11 Fisheye Setting, GV-QFER12700 User's Manual.				



6. Upgrading System Firmware

GeoVision periodically releases the updated firmware on the <u>website</u>. To load the new firmware into the camera, follow the instructions below.

1. Select **System** from the top menu > **Software Upgrade**. This page appears.

	Home System Streaming Image Logout					
System	Software Upgrade					
Network V	Step1:					
DDNS	Upload the binary file					
FTP	Step2:					
нттр	Select binary file you want to upgrade ulmage+userland.img					
Storage Management	Step3:					
Recording	Upgrade Dutton to start the upgrade process					
Schedule File Location						
View Information						
Factory Default Software Version						
Software Upgrade						
Maintenance						

- 2. In Step 1, click the **Browse** button to locate the firmware file saved at your local computer.
- 3. In Step 2, select the type of the firmware file.
- 4. In Step 3, click Upgrade.

Note: See details in 2.2.16 Software Upgrade, GV-QFER12700 User's Manual.

7. Restoring to Factory Default

If for any reason the camera is not responding correctly, you can restore the camera to its factory default settings using the Web interface.

1. Select **System** at the top > **Factory Default**. This page appears.

GeoUision	Home	System	Streaming	Image	Logout	
System	Factory Def	ault				
Security T						
Network 🔻	Dentena (e					
DDNS	Restore ta	ictory settin	gs and lose any	y cnanges?		
Mail	System w	in restart an	a need installe	r program to	5 setup netw	/ork.
FTP	Tuli Resi	lore				
нттр						
Events 🔻						
Storage Management	Restore fa	actory settin	gs (excluding r	etwork sett	ings/User s	ettings)
Recording	Partial R	estore				
Schedule						
File Location						
View Information	Reboot th	e system.				
Factory Default	Reboot]				
Software Version						

2. Select Full Restore, Partial Restore, or Reboot.

Note: See details in 2.2.14 Factory Default, GV-QFER12700 User's Manual.